

# IRVING OIL

Revere, MA, Terminal Spec Sheet

## Contact Information

**Address:**  
41 Lee Burbank Highway  
Revere, MA  
02151

**Phone:** 781.289.4201

**Fax:** 781.289.3229

**Customer Service:** 1.866.865.8800

**Hours of Operation:**  
24/7, 365 days a year

## Lane Configuration

	Bay 1	Bay 2	Bay 3	Bay 4	Bay 5	Bay 6	Bay 7	Bay 8	Bay 9	Bay 10	Bay 11	Bay 12
Loading	Bottom	Bottom	Bottom	Bottom	Bottom	Bottom	Bottom	Bottom	Top	Bottom	Top	Bottom
10% Ethanol Blended Gasoline	✓✓	✓✓	✓✓	✓✓	✓✓	✓✓	✓✓					
Ultra Low Sulphur Diesel (Clear & Dyed)						✓	✓	✓✓	✓	✓✓	✓	✓✓
ProHeat						✓	✓	✓✓	✓	✓✓	✓	✓✓
#2 Fuel Oil 500 PPM								✓✓	✓	✓✓	✓	✓✓
Dial a Cloud ULSD						✓	✓		✓			✓

**IMPORTANT:** Please review the terminal orientation process on the reverse side.

Please contact our Customer Support Team at **1.866.865.8800** or **IOCCustomerSupport@irvingoil.com** to be directed to the sales representative in your area.

# IRVING OIL

Revere, MA, Terminal Spec Sheet

## Terminal Orientation

To ensure your first lifts are made easily and safely, we offer training for drivers.

### STEP 1 – Complete our Compliance Checklist

Please ensure you have the document listed below before your orientation training. Each of these documents must be with you during every visit to our terminal.

#### Carrier Requirements:

- Carrier insurance certificate
- Terminal access agreement

#### Trailer Requirements:

- Annual visual inspection
- 5 year inspection
- Probe certification

#### Driver Requirements:

- Hazard endorsement
- TWIC requirements
- Valid Drivers License

### STEP 2 – Schedule an Appointment

To schedule your driver orientation training, please call the Revere Marine terminal (781.289.4201) more than 24 hours in advance.

### STEP 3 – Attend the Training

- The driver orientation training takes about one to two hours.
- Training includes an orientation video, review of standards and procedures, site orientation, supervised loads, and compliance checklist.
- To make the orientation faster and more efficient, you may send an experienced driver along with your new driver.
- Drivers must have ten supervised loads and meet our compliance checklist prior to receiving their access card.
- Completion of orientation is required every three years.

If you have any questions, please contact our Customer Support team at **1.866.865.8800** or by email at [IOCCustomerSupport@irvingoil.com](mailto:IOCCustomerSupport@irvingoil.com).

Thanks for your business, and we look forward to serving you.